













Please retain this information  
for future reference

# wooden doll house

## Assembly instructions

	 A=16pcs		
			
			

**WARNING:**  
ADULT ASSEMBLY REQUIRED. Product includes small parts with potentially hazardous sharp points and sharp edges in the unassembled state. Keep unassembled parts away from children.

**WARNING: CHOKING HAZARD.** Small parts and sharp points, not suitable for children under 3 years.

**WARNING:** If used improperly, your toys may be pulled over or fall, creating risk of injury or damage. To minimize this risk, We recommend that you use a fixed accessories.

